


HOFFMANN POWER PRODUCTS

PARTS LIST 2012

6Y-7Y-10Y-14Y - PETROL



ALL PARTS ARE SUBJECT TO STANDARD HOFFMANN TERMS AND CONDITIONS OF SALE 2010


Replacement parts are not manufactured, sold or warranted by O.E.M's and any part numbers and or descriptions are used for identification purposes only.

Manufacturers names, numbers and descriptions are used for reference purposes only and it is not implied that any part listed is the product of the manufacturers.


All pictures and drawings are for reference purposes only; any specifications appearing in any documents emanating from The Company are approximate only and are subject to modifications without notice.

All rights reserved, material contained in this publication for which copyright is acknowledged. No part of this publication may be reproduced or transmitted in any form or by any means without written permission of the copyright holder. Copyright Hoffmann International©2012.


CYLINDER HEAD




CRANK CASE




CRANK CASE COVER




CRANKSHAFT/PISTON




GAS DISTRIBUTION ADJUSTMENT




STARTER SUBASSEMBLY




DIVERSION ASSY.




CARBURETOR




FLYWHEEL/COIL ASSY.




STARTER MOTOR




CONTROL SYSTEM




AIR CLEANER




MUFFLER




FUEL TANK






CYLINDER HEAD

No	Description	QTY.		Part No.
1	Head Cylinder (bare)	-	1	01020000
2	Bolt, Stud, In.	2	2	01000004
3	Bolt, Stud, Ex.	2	2	01000005
4	Cover Head	1	1	01010000
5	Packing, Head Cover	1	1	01000001
6	Tube, Breather	1	1	04010015
7	Plug, Spark	1	1	01020015
8	Gasket, Cylinder Head	-	1	01000003
9	Gasket, Muffler	1	1	05000001/3
10	Pin, Dowel	2	2	02000002
11	Bolt, Flange, 6*12	4	4	14Y-GB5787-86
12	Bolt, Flange, 8*60	4	4	GBT5787-86/8X6




CRANKCASE

No	Description	QTY.		Part No.
1	Crankcase		1	02010000
2	Oil Level Switch	1	1	09020000
5	Governor Assy	1	1	07000000
6	Bolt, Flange 6x8	1	1	Local
8	Shaft, Governor Arm	1	1	07000001
9	Bolt, Drain Plug	2	2	02010003
11	Washer, Drain Plug	2	2	02010004
12	Alert Unit, Oil	1	1	09030000
13	Bearing, Radial Ball	1	1	GBT276-6205
14	Oil Seal 25x41.25x6	1	1	02010002
16	Nut 10 mm	1	1	MS15-017010
17	Washer 6x13x1	1	1	5VX-M6X13X1
18	Pin, Lock	1	1	07000006
19	Bolt, Flange, 6x12	2	2	14Y-GB5787-86




CRANKCASE COVER

No	Description	QTY.		Part No.
1	Bolt, Flange	6	6	GB5787-86/8x32
4	Case Cover	1	1	02040000
5	Oil Seal	1	1	02010002
6	Bearing	1	1	GBT276-6205
7	Pin, Dowel	2	2	02000004
9	Packing, Case Cover	1	1	02000001
10	Oil Filler Assy	1	1	02040002
11	Cap Assy	1	1	02040001
12	Bolt, Flange	1	1	GB5782-86/8x40




CRANKSHAFT/PISTON

No	Description	QTY.		Part No.
1	Ring Set		1	03010002
2	Piston		1	03010001
3	Pin, Piston		1	03000001
4	Rod Assy., Connecting		1	03020001
5	Crankshaft Comp.		1	0202004I
6	Clip, Piston Pin		2	03000002
7	Key		1	02030003




GAS DISTRIBUTION ADJUSTMENT

No	Description	QTY.		Part No.
1	Nut, Pivot Adjusting	2	2	01020011
2	Pivot, Rocker Arm	2	2	01020010
3	Arm, Valve Rocker	2	2	01020009
4	Bolt, Pivot, Arm	2	2	01020012
5	Valve, In.	1	1	01020001
6	Valve, Ex.	1	1	01020002
7	Plate, Push Rod Guide	1	1	01020013
8	Rod, Push	2	2	02000003
9	Lifter, Valve	2	2	106001
10	Radiator, Valve	2	2	106006
11	Retainer, Valve Spring	2	2	01020008
12	Spring, Valve	2	2	01020003
13	Seal, Guide	1	1	01020006
14	Camshaft Assy.	1	1	02030000




STARTER SUBASSEMBLY

No	Description	QTY.		Part No.
1	Starter Assy.	1	1	08010000
3	Guide, Ratchet	1	1	08010006
4	Spring, Friction	1	1	08010007
5	Ratchet, Starter	2	2	08010010
6	Spring, Return	2	2	08010009
7	Reel, Recoil Starter	1	1	08010004
8	Spring, Recoil Starter	1	1	08010003
9	Recoil Starter Handle	1	1	08010002
11	Rope	1	1	08010005
12	Bolt, Flange 6 x 8	4	4	Local
13	Bolt, Flange 6 x 12	4	4	14Y-GB5787-86
14	Cover Comp., Fan	1	1	08000001
15	Switch Assy., Engine Stop (Oil Alert)	1	1	09030000
17	Switch Assy., Engine Stop	1	1	09010000




DIVERSION ASSY

No	Description	QTY.		Part No.
1	Bolt, Flange 6 x 8	2	2	Local
2	Shroud Comp	1	1	10000002




CARBURETTOR

No	Description	QTY.		Part No.
1	Carburettor	1	1	04020000
3	Carb Emulsion Tube	1	1	040200ET
4	Jet, Main	1	1	040200MJ
7	Float	1	1	040200FL
9	Gasket, Oil Cup	1	1	040200CS
22	Packing, Carburettor	1	1	04000004
23	Insulator, Carburettor	1	1	04000001
24	Packing, Insulator	1	1	04000002




FLYWHEEL/COIL ASSY.

No	Description	QTY.		Part No.
1	Coil Assy., Ignition	1	1	09040000
3	Cap Assy., Noise Suppressor	1	1	09040001
5	Bolt, Flange, 6 x 25	2	2	GB5787-86/6X25
6	Flywheel Comp.	1	1	09050000
8	Fan, Cooling	1	1	10000001
9	Pulley, Starter Cup	1	1	08000003
10	Nut, Special	1	1	08000004
11	Flywheel Comp	(1)	(1)	09050000
13	Bolt, Flange, 6 x 28	2	2	Local
15	Bolt, Flange 6 x 8	(1)	(1)	Local




CONTROL SYSTEM

No	Description	QTY.		Part No.
1	Bolt, Flange	2	2	GB5787-86/6x10
2	Spring, Governor	1	1	07000002
3	Bolt, Quadrate Head	1	1	07000007
4	Arm, Governor	1	1	07020007
5	Nut, Flange 6mm	1	1	GB6177-8616
6	Spring, Throttle Return	1	1	07000003
7	Rod, Governor	1	1	07000004
8	Control Assy.	1	1	07010000
9	Spring	1	1	N/A
10	Screw, M5x35	1	1	Local




AIR CLEANER

No	Description	QTY.		Part No.
1	Elbow Comp., Air Cleaner	1	1	04010002
2	Elbow Top	1	1	T/F
3	Packing, Elbow	1	1	04010008S
4	Cover, Air Cleaner	1	1	04010010
5	Nut, Tool Box Setting	1	1	04010014
6	Element Assy., Air Cleaner	1	1	04010100
7	Air Filter Base	1	1	04010004
8	Screw	2	2	Local
9	Nut, Flange, 6 mm	2	2	GB6177-8616
10	Air Cleaner Assy	1	1	T/F
11	Bolt, Flange, 6 x 20	1	1	GB5787-86/6X20



MUFFLER

No	Description	QTY.		Part No.
1	Muffler Comp.	1	1	05010000
4	Screw, Tapping, 5 x 10	2	2	Local
5	Bolt, M8 X 25	1	1	GB5783-M8X25



No	Description	QTY.		Part No.
1	Clip, Tube	2	2	06000003
2	Fuel Filter	1	1	06000001
3	Tank Comp., Fuel	1	1	06010000
4	Cap Comp., Fuel Filler	1	1	06020000
6	Fuel Tank Strainer	1	1	06000004
7	Bolt, Flange, 6x12	4	4	8Y-GB5787-86
9	Fuel Tank Rear Bracket	1	1	0601/BR-RR
10	Tube, Fuel	1	1	06000005
12	Fuel Tank Front Bracket	1	1	0601/BR-FR
14	Bolt, Flange, 6x25	1	1	GB5787-86/6x25